peerless-AV™

Installation and Assembly:
Accessory Laptop Cooling Tray

Model: ACC329



DESKTOP ARM
(SOLD SEPARATELY)

For use with:

LCT420A
LCW420A
LCT620A
LCW620A
LCT620AD
LCW620AD

Max Load Capacity: 19.8 lb (9 kg)

2300 White Oak Circle • Aurora, Il 60502 • (800) 865-2112 • Fax: (800) 359-6500 • www.peerless-av.com

ISSUED: 07-10-12 SHEET #: 120-9160-1

NOTE: Read entire instruction sheet before you start installation and assembly.

⚠ WARNING

- Do not begin to install your Peerless product until you have read and understood the instructions and warnings contained in this Installation Sheet. If you have any questions regarding any of the instructions or warnings, for US customers please call Peerless customer care at 1-800-865-2112, for all international customers, please contact your local distributor.
- This product should only be installed by someone of good mechanical aptitude, has experience with basic building construction, and fully understands these instructions.
- Make sure that the supporting surface will safely support the combined load of the equipment and all attached hardware and components.
- Never exceed the Maximum Load Capacity. See page one.
- Tighten screws firmly, but do not overtighten. Overtightening can damage the items, greatly reducing their holding power.
- This product is intended for indoor use only. Use of this product outdoors could lead to product failure and personal injury.

Tools Needed for Assembly

- phillips screwdriver
- 4mm allen wrench

Before you begin, make sure all parts shown are included with your product.

Parts List

	Description	Qty
A	laptop tray	1
B	screw knob	4
C	USB powered fan	1
D	square pad	2

Parts may appear slightly different than illustrated.









1 Loosen tilt screw and set screw shown in detail 1 and 2 to adjust height of arm and degree of tilt on adapter plate to desired location. Adjust arm and adapter plate then retighten screws.

fig. 1.1



fig. 1.2



2 Attach laptop tray (**A**) to adapter plate of desktop arm with four screw knobs (**B**).



3 Apply two square pads (**D**) to top of laptop tray.



4 Open laptop and place into cradle of laptop tray (**A**).



5 Press fit USB powered fan (**C**) into ventilation grid of laptop tray underneath laptop fan. No screws required.
NOTE: Be sure label of fan faces away from laptop tray.

fig. 5.1



fig. 5.2



6 Hold laptop securely to tray, make final height or tilt adjustments then tighten all screws as shown in detail 3 and 4.



ISSUED: 07-10-12 SHEET #: 120-9160-1

© 2012 Peerless Industries, Inc. All rights reserved.
All other brand and product names are trademarks or registered trademarks of their respective owners.

LIMITED FIVE-YEAR WARRANTY

Peerless Industries, Inc. (“Peerless”) warrants to original end-users of Peerless® products will be free from defects in material and workmanship, under normal use, for a period of five years from the date of purchase by the original end-user (but in no case longer than six years after the date of the product’s manufacture). At its option, Peerless will repair or replace, or refund the purchase price of, any product which fails to conform with this warranty.

In no event shall the duration of any implied warranty of merchantability or fitness for a particular purpose be longer than the period of the applicable express warranty set forth above. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

This warranty does not cover damage caused by (a) service or repairs by the customer or a person who is not authorized for such service or repairs by Peerless, (b) the failure to utilize proper packing when returning the product, (c) incorrect installation or the failure to follow Peerless’ instructions or warnings when installing, using or storing the product, or (d) misuse or accident, in transit or otherwise, including in cases of third party actions and force majeure.

In no event shall Peerless be liable for incidental or consequential damages or damages arising from the theft of any product, whether or not secured by a security device which may be included with the Peerless® product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

This warranty is in lieu of all other warranties, expressed or implied, and is the sole remedy with respect to product defects. No dealer, distributor, installer or other person is authorized to modify or extend this Limited Warranty or impose any obligation on Peerless in connection with the sale of any Peerless® product.

This warranty gives specific legal rights, and you may also have other rights which vary from state to state.

peerless-AV™

www.peerless-av.com

© 2012 Peerless Industries, Inc.